Crystal structure analysis of high temperature neutron diffraction data of novel oxide-ion conducting materials

Kotaro Fujii, Ayaka Fujimoto, Wataru Uno, Keigo Nakamura, Masatomo Yashima *Tokyo Institute of Technology*

Oxide-ion conductors, which include pure ionic conductors and mixed oxide-ion and electronic conductors, attract significant interest because of their varied uses in oxygen separation membranes and cathodes for solid-oxide fuel cells (SOFCs). The oxide-ion conductivity is strongly dependent on the crystal structure. At present, several structures, such as fluorites, perovskites, K₂NiF₄, mellilites, and apatites, are known to show high oxide-ion conductivities. For further development of oxide-ion conductors is investigating materials with new types of structures. According to such background, we are exploring new structure family of oxide-ion conductors. For example, we have discovered a new structural family of oxide-ion conductor NdBaInO4 which has a monoclinic $P2_1/c$ perovskite-related phase with a layered structure, in 2014. cently, we found novel material, SrRInO₄ (R : rare earths) with CaFe₂O₄-type structure showed high oxide-ion conductivity compared to the other CaFe₂O₄-type materials. In order to understand the mechanism of oxide-ion conduction, it is necessary to precisely determine the crystal structure (particularly position, occupancy factor, and anisotropic displacement parameters of oxygens) at high-temperature because oxide-ion conductors are generally used at high-temperature. In the present study, we investigated the crystal structure of SrRInO₄ (R : rare earths) at high temperature using high resolution neutron powder diffractometer Echidna installed at the research reactor OPAL, ACNS, ANSTO. The materials were prepared by the solidstate reactions. The sintered pellets of the reaction products were introduced into a vanadium can and used for the neutron diffraction experiment. The measurements

were carried out from room temperature to high temperature (1000 °C) at 200 °C intervals. Each measurement time was few hours. The structural analyses for these data are carried out by Rietveld method using the program RIETAN-FP. The result of the Rietveld refinement at the room temperature 23 °C is shown in Figure (R_{wp} =3.78 %, R_B = 3.82 %). For the diffraction data at 800 °C, the final Rietveld plot gave R_{wp} = 5.45 %, R_B = 6.35 % (see Figure for the fitting). Currently further structure analysis is ongoing.




Fig. 1. Rietveld plots of SrRInO4 based material